



Introducing the Desktop Printer Battery Accessory

Easily power your Zebra ZD Series Desktop printer on a cart for on the spot printing.

- **Field installable** – The battery accessory is designed for all models of the ZD410, ZD420 and ZD620 desktop printers. The battery pack fits into the accessory housing which mounts to the printer base. Four screws attach the housing to the printer.
- **Powerful** – The fully charged battery powers the printer for a full day¹ of printing at typical darkness and print speed. Supports all connectivity options including wireless radio.
- **Compatible with all printer configurations** – The battery will power a printer with wireless radio configuration, a cutter, peeler or Keyboard Display Unit (KDU) attached.
- **Flexible** – The battery is easily removed from the housing to be charged outside of the printer using the standard printer power supply.
- **Battery charge level indicator** – The indicator makes it easy to see when the battery charge level is getting low and needs to be charged.
- **Easy connection** – The battery connects to the existing power input jack. No additional wires or loose items to tangle or lose.
- **Compact design** – The battery accessory doesn't change the footprint of the printer.



¹Full day of printing is two rolls of media.

NA and Corporate Headquarters
+1 800 423 0442
inquiry4@zebra.com

Asia-Pacific Headquarters
+65 6858 0722
contact.apac@zebra.com

EMEA Headquarters
zebra.com/locations
contact.emea@zebra.com

Latin America Headquarters
+1 847 955 2283
la.contactme@zebra.com